



Notes:

1. Trade waste specifications for connection to sewer.
2. Sealed disconnected gullies must be vented. Disconnecter gully caps must be removable for sampling purposes.
3. The sample valve and disconnecter gully are required for sampling purposes.
4. The interceptor and baffle shall be constructed from a material that is suitable for the quality of the waste.
5. Polyvinyl chloride (PVC) shall not be used for the construction or venting of this interceptor including all pipework upstream of the interceptor.
6. Airtight covers are compulsory and vents are to be extended to open air in accordance with the relevant plumbing regulations.
7. The interceptor must be located in a position to provide ready access for maintenance and inspection purposes.
8. The interceptor is to be constructed, installed, and connected in accordance with the relevant plumbing regulations.
9. The interceptor may accumulate quantities of explosive and/or flammable materials and therefore care must be exercised in the maintenance and general use.
10. Minimum water capacity of the interceptor below the invert level of the outlet pipe is 100 litres unless otherwise specified in the Trade Waste consent/agreement
11. This interceptor can only be used above ground. An oil interceptor can be used for below ground installations.
12. Drain valve to be used for the removal of the floating solvent layer by licensed waste transporter. The entire contents may need to be pumped out if specified in the Trade Waste Consent.
13. Usages; schools, small lab sinks, small degreasing troughs for parts washing, silk screen printing, small troughs for enamel paint washing, etc.
14. GWW area; Contact GWW for clarification of when to use, or for additional information.
15. Before any trade waste apparatus is installed it must be reviewed and accepted by the SEW / YVW / GWW trade waste team, and subsequently included in a Trade Waste consent/agreement.
16. All dimensions in millimetres (mm) unless specified otherwise.

For more information contact the trade waste team on:

South East Water: **1300 634 712** or tradewaste@sew.com.au

Yarra Valley Water: **1300 771 865** or commercialcustomer care@yvwm.com.au

Greater Western Water: **13 44 99** or tradewaste@gww.com.au

Solvent and oil interceptor (for trace elements only)

DRAWING NO:

AM 9

REVISION:

2

SCALE:

NTS

DATE:

Aug 25

